

How to use I-CubeX with ... Live 4.0

I-CubeX: The ultimate MIDI controller!

Infusions Systems Ltd. 2033 Avenue de Vendome Montreal, Qc Canada H4A 3M4

Toll free (USA/Canada): 1 877 4 ICUBEX (1 877 442 8239) Tel: +1 (514) 484 5850 Fax: +1 (514) 484 5852

Email: info@infusionsystems.com http://www.infusionsystems.com



June 14th 2005 © 1997-2005 Infusion Systems



The goal of this tutorial is to get you started using your I-CubeX system with the Ableton Live software.

We assume that you already have the I-CubeX editor installed, if not, please refer to the I-CubeX editor tutorial.

You will first need to configure your I-CubeX digitizer with the editor. Plug the different sensors you'd like to use and open the editor. Add the different sensors using the configure menu. (fig. 1)







Abelton Live will understand Pitch Bend, Control Changes and Note messages. It is recommended to use Control Change or Pitch Bend for continuous values (like the Push or Turn sensors) and Note messages for on/off values (TapOn, MoveOn). (fig. 2) Make sure all the sensors output their values using different Control Change numbers (or channels if using Pitch Bend).

In Ableton Live, you will need to configure your midi input. To do so, go in the Options menu and choose Preferences. (fig. 3) Select the midi / sync tab. In the Active Devices section, you will see a list of your different midi devices. (fig. 4) In the Input field, locate the midi device your I-CubeX is connected to and make sure it is activated (the square left to the device name should be green). (fig. 5) In the Remote Control section under Input, select the proper midi device. (fig. 5) Once this is done, you can close the window.

: with	Live - Live		Preferences	×
View	Options Help			
14	Edit MIDI Map Edit Key Map	Ctrl+M 1	Audio MIDI / Sync Plug-In Defaults Misc	
ctory	External Sync		Active Devices	
and Tu	External Sync		Topologi general	
o Soun	Time Ruler Format	t + 6	Input Output	A Marco and A Marco and
ke Mus	Narrow Grid	Ctrl+1	Computer Keyboard Microsoft GS Wave	table SW S
iting Ar	Widen Grid	Ctrl+2		
DI Instri	Triplet Grid	Ctrl+3		
ating F	Snap To Grid	Ctrl+4		
cord ar	Draw Mode	Ctrl+B		
es	Follow	Ctrl+F	Remote Control	
Hits	Solo Switches			_
Drum_	Cue Switches		Input Output	
dwig	Lody Freudance		None	
Ludwig	MIDI Overdub		None Send Lindet	
Drum_	MIDI OVERGOD			<u></u>
CACOU	Preferences			
CEIBCD.C			Sync	
Figure 3			Figure 4	

riyule 4

Audio MiDi / Sync Plug-in	Defaults Misc				
Active Devices					
Input	Output				
Computer Keyboard In USB Midi 1x1	Microsoft GS Wavetable SW S Out USB Midi 1x1				
Remote Control					
Input	Output				
None 👻	None				
None	Sand Lindatas				
In USB Midi 1x1	Send Opdates				
Sync					

Figure 5

Looking at Live's main interface, you should see two small squares to the upper right next to the letter "D". (fig. 6) The one at the top should flash when you tweak one of your sensors; this is the midi in activity indicator.



In order to associate a sensor with an on-screen control, you will need to click the Midi Map button located at the upper right of the interface. (fig. 6) You will notice that parts of the UI are now blue, this blue overlay shows you which elements are controllable in Live. (fig. 7)



To map a control, click it with the mouse and tweak the desired sensor. Two numbers should appear, the first one represents the Control Change number and the second one represents the channel number. (fig. 8) Click the Midi Map button again and your control should now be mapped to the sensor. The small square left to the Midi Map button should now flash instead of the one located next to the "D" letter. (fig. 6)

When working with multiple sensors, it might be hard to assign the right sensor to the right UI element. In order to properly set up your mapping, you will need to activate one sensor at a time in the editor. To do so, switch off all the sensors you don't want to map and leave the one you want to assign to On. (fig. 9) Once assigned, repeat for the other sensors. This will be useful for sensors sending 2 messages at the same time (ie. Gforce2D) because Live will get confused about what it is receiving.